

Roborock Dyad Pro

Wet and Dry Vacuum Cleaner User Manual

Read this manual carefully before using this product and
store it properly for future reference.



| | |
|-----------------|-----------|
| English | 03 |
| Français | 11 |
| Deutsch | 18 |
| Italiano | 25 |
| Español | 32 |
| Polski | 39 |
| Norsk | 46 |
| Svenska | 53 |

Contents

| | |
|----|------------------------------|
| 04 | Safety Information |
| 05 | Product Introduction |
| 05 | Product Installation |
| 05 | Connecting to the App |
| 06 | Instructions for Use |
| 07 | Routine Maintenance |
| 08 | Basic Parameters |
| 09 | Common Issues |
| 10 | EU Declaration of Conformity |
| 10 | WEEE Information |
| 10 | Warranty Information |

Safety Information

Usage Restrictions

- Do not use this vacuum outdoor or in any commercial or industrial environments. It is intended for home use only.
- Do not store the vacuum anywhere in a car to avoid high or low temperatures affecting its battery life.
- Do not use the vacuum in environments with high humidity, or temperatures above 40°C or below 4°C.
- Use the maintenance brush carefully to avoid injury. Keep out of reach of children.
- Children should be supervised to ensure that they do not play with the appliance.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety (CB).
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision (EU).
- To satisfy RF exposure requirements, a separation distance of 20 cm or more should be maintained between this device and persons during device operation. To ensure compliance, operations at closer than this distance is not recommended.

- The antenna used for this transmitter must not be co-located in conjunction with any other antenna or transmitter.
- Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
- Keep limbs and pets away from the rotating brush heads to avoid injury.
- Do not touch the power supply, nor operate the product with wet hands to prevent injuries.
- Do not vacuum any burning or smoking substances (such as non-extinguished cigarette butts).
- Do not vacuum any hard or pointy objects (such as building materials, glass, and nails).
- Please use this product in accordance with the instructions in the User Manual. Users are responsible for any loss or damage that may arise from improper use of this product.
- This product is only to be used in areas below 3,000 meters above sea level.

Battery and Charging

WARNING

- Do not charge non-rechargeable batteries.
- This product contains batteries that are only replaceable by skilled persons.
- This product can only be charged using a YJS060P-3001900G, E060-1P300190VE or E060-1P300190VA power supply provided with the product.
- Do not use any third-party batteries, power adapters or docks.
- To reduce the risk of injury from moving parts, keep the power off before servicing.
- Do not disassemble, repair or modify the battery, power adapter or the dock.
- Do not charge the vacuum or install the dock near heat sources or in humid areas (such as radiators or bathrooms).

- Do not wipe the adapter or the dock with a wet cloth, nor touch them with wet hands.
- If the power cord is damaged or broken, immediately stop use and contact after-sales service.
- If the vacuum is not going to be used for an extended period of time, fully charge it, unplug its power supply, and place it in a cool and dry place.
- Make sure that you recharge it once every three months to avoid the battery to over-discharge.

Transportation

- It is recommended to transport the vacuum in its original packaging.

Note

- Rinse the filter at least once a month with tap water. For details please refer to Maintenance.

A Product Introduction

A1 Vacuum Cleaner

— Self-Clean

- Press: Standard mode
- Press and hold for 2s: DEEP mode

— Change Mode

- Press: Switch to AUTO/MAX/Floor Drying/ECO mode

— Power

- Press: Start/Pause
- Press and hold for 2s: Switch off
- Press while charging: Start/Stop drying

A1-1—Handle

A1-2—LED Display

A1-3—Clean Tank Release

A1-4—Clean Tank

A1-5—Dirty Tank Release

A1-6—Dirty Tank

A1-7—Detergent Cartridge

A1-8—Cleaning Head

A1-9—Splash Guard Lift Toggle

A1-10—Front Rollers

A1-11—Rear Roller

A2 Screen Functions

A2-1—ECO Mode

A2-2—Charging

A2-3—Battery Level

A2-4—Clean Tank Empty

A2-5—Dirty Tank Full

A2-6—Dirt Level

A2-7—AUTO Mode

A2-8—MAX Mode

A2-9—Floor Drying Mode

A2-10—WiFi Indicator

- Off: WiFi disabled
- Flashing slowly: Waiting for connection
- Flashing quickly: Connecting
- Steady on: WiFi connected

A2-11—Error

A2-12—Drying

A2-13—Self-Cleaning

A3 Drying & Charging Dock

A3-1—Body

A3-2—Tray

A4 Power Supply

A5 Filter

A6 Maintenance Brush

A7 Dirty Water Tank Cover

A7-1—Water Level Sensors

B Product Installation

B1 Setting Up the Vacuum Cleaner

B1-1— Insert the handle into the vacuum body until it clicks in place. The power button should face forward.

B1-2— To remove the handle, remove the clean tank and then gently pull the handle while pressing the release button on the vacuum body.

B2 Charging Dock Installation

B2-1—Align the charging dock tray with the charging dock body, press down, making sure they are firmly secured.

B2-2—Connect the power supply into the bottom of the charging dock and plug it in. Power cable can exit from either side.

Note: For long-term storage, unplug your machine to save energy.

B2-3—To disassemble the charging dock, grasp the side handles of the tray and pull upward.




Connecting to the App

1 Download the App

Search “Roborock” in the App Store or Google Play or scan the QR code below to download and install the app.



2 Reset WiFi

- Keep the machine upright and press  to light up the screen. The machine will enter wait-for-orders mode.
- Press and hold  and  until you hear the “Resetting WiFi” voice alert. The reset is complete when the WiFi indicator flashes slowly. The vacuum cleaner will then wait for a connection.

Note: If the mobile phone fails to connect to the vacuum cleaner because your router configuration has changed or you forget your password or for any other reasons, reset WiFi and add your device again.

③ Add the Device

On the Roborock App, tap “+” on the home page, and add the device as instructed in the app.

Notes:

- The actual process may vary due to ongoing app updates. Follow the instructions provided in the app.
- Only 2.4 GHz WiFi is supported.

Ⓒ Instructions for Use

Ⓒ1 Filling the Clean Tank

C1-1—Push the Clean Tank Release and remove the tank.

C1-2—Open the plug, fill it with tap water, and then close it tightly. The water level should not exceed the MAX line.

C1-3—Reinstall the Clean Tank bottom first then push forward to secure it in place.

Note: To avoid deforming the Clean Tank, only use cold water.

Ⓒ2 Adding Detergent

C2-1—Push the detergent cartridge release button and remove the cartridge.

C2-2—Open the detergent cartridge, fill it with detergent, and then close it tightly.

C2-3—Reinstall the detergent cartridge.

Notes:

- The detergent cartridge requires refilling after about 20 tanks of clean water.
- Remove the detergent cartridge if it is deemed unnecessary.
- To prevent corrosion or damage, only use detergent recommended by Roborock.

Ⓒ3 Locking and Unlocking

C3-1—Tap the side of the cleaning head

without the detergent cartridge, and push the handle to lock the cleaning head or pull the handle to unlock the cleaning head.

C3-2—Locked

C3-3—Unlocked

Ⓒ4 Starting the Vacuum Cleaner

Unlock the cleaning head, tilt the body and press the power button to start the vacuum cleaner.

C4-1—Do not tilt over 60°

C4-2—Caution

In order to prevent dirty water from leaking out, do not lay the body flat or tilt it over 60° when dirty tank in place.

Notes:

- The cleaning head does not work when locked. Unlock it first.
- Press power button can only start drying when the vacuum cleaner is charging.

Switching Modes

Press the change mode button to switch to AUTO, MAX, Floor Drying or ECO mode. The screen will display the icon for the current mode.

Notes:



- Floor Drying mode is for removing clean water from wet environments such as bathrooms. It should not be used when water depth exceeds 10mm (0.4in).
- Floor Drying mode is limited to one minute. After which, AUTO mode will resume.

Ⓒ5 Adjusting the Splash Guard

You can adjust the splash guard using the lift toggle. You can raise it to collect large pieces of waste on the floor and lower it to prevent the

cleaning head from getting stuck when there are many objects on the floor.

Wait for Orders and Power Off

1. When the vacuum cleaner is operating, press the  button to pause it and make it enter wait-for-orders mode.
2. In wait-for-orders mode, you can lock the cleaning head and place the vacuum cleaner upright on the floor.
3. Lock the cleaning head and press and hold the  button for 2 seconds to turn off the vacuum cleaner. If the vacuum cleaner is left idle for 5 minutes in wait-for-orders mode, it will automatically turn off.

Note: You can modify the settings in the app to enable automatically resume operation after unlocking the cleaning head.

Adding and Emptying Water

When the dirty tank is full or the clean tank is empty during use, the vacuum cleaner will provide audio and visual alerts. Add water into the clean tank or empty the dirty tank before continuing.

Ⓒ6 Emptying the Dirty Tank

C6-1—Push the dirty tank release and remove the tank.

C6-2—Hold the handle firmly with one hand, and gently lift out the cover.

C6-3—Pour out the dirty water. If there is any solid dirt in the tank, filter it using the filter at the bottom of the cover.

C6-4—Reinstall the cover, tilt the dirty tank, install the bottom in place, and then gently push it inward to secure it in place.

C7 Charging and Self-Cleaning

1. Lock the cleaning head, and place the vacuum cleaner onto the charging dock. The voice alert "Charging" indicates that the vacuum cleaner is charging.
2. Press the Self-Clean button to start standard self-cleaning. Press and hold the clean button for 2 seconds to switch to DEEP self-cleaning mode.
3. After self-cleaning finishes, empty the dirty tank to prevent odor.

Notes:

- The product is equipped with a built-in high-performance lithium-ion rechargeable battery pack. To maintain battery performance, keep the product charged for normal use.
- Always place the vacuum cleaner on the charging dock after use to prevent water stains.



Drying

Drying starts automatically after self-cleaning is completed. To manually start or stop drying, press the power button on the docked vacuum cleaner.

Voice Alert Settings

Connect to the app to adjust the volume of voice alerts.

Deactivating WiFi

To disconnect the vacuum cleaner from WiFi, press the  and  buttons until you hear a voice message. Then wait for 5 minutes and the WiFi will be automatically deactivated. If you want to reconnect, please follow the related connecting instructions.

D Routine Maintenance

To maintain optimal performance of the product, refer to the following table for routine maintenance.

| Parts | Maintenance Frequency | Replacement Frequency |
|------------------------------------|-----------------------|-----------------------|
| Roller | 2-4 weeks | 6-12 months |
| Filter | 1 month | 6-12 months |
| Cleaning head and dirty water pipe | 1 month | N/A |
| Dirty tank | 1 month | N/A |
| Dirty water level sensor | 1 month | N/A |
| Charging dock tray | As needed | N/A |
| Charging contact | 1 month | N/A |

Product Maintenance

If this product is left unused for a prolonged period of time, fully charge it and unplug it before storing it in a cool and dry place. Do not place the product in humid locations or under direct sunlight. Charge it at least once every 3 months to avoid overdischarge.

Cleaning the Body

Wipe and clean the body with a soft and dry cloth. Before cleaning, unplug the power supply and keep the vacuum cleaner off.

D1 Cleaning the Dirty Tank and Filter

- D1-1**—Take out the dirty tank, pull out the cover, and open the water level sensors. Clean the parts with the provided maintenance brush, rinse them with cold water, and then snap the water level sensors back in place.
- D1-2**—Take out the filter from dirty water tank cover and remove any trash attached to the filter. If the filter is dirty, rinse it with cold water and then shake off the residual water.
- D1-3**—Allow up to 24 hours for all parts drying and install them back in place.

Notes:

- Use a second filter if necessary.
- Do not touch the filter with your hands, brushes, or sharp objects to avoid damage to the filter.

D2 Cleaning the Rollers

1. Remove the vacuum cleaner from the charging dock, switch it off.
 2. Place the vacuum on a hard and flat floor and lock the cleaning head.
- D2-1**—Rotate the rear roller cover to the unlock position, and pull the rear roller outward.
- D2-2**—Pinch the left and right front rollers with both hands, and pull them outward.

D2-3—Cut off any hair entangled on the rollers and remove any debris using the provided maintenance brush.

Note: Use the maintenance brush carefully to avoid injury.

D2-4—Insert the rear roller from the side, and then rotate the rear roller cover from the unlock position to the lock position until it clicks in place.

D2-5—To install the front rollers, marked red and blue, on the correct sides of the head. Pinch them with both hands and align them with the front roller shaft. Push inward to install properly.

D3 Cleaning the Cleaning Head and Dirty Water Pipe

1. Remove the dirty tank and front and rear rollers. Switch off the vacuum cleaner and stabilize the body.
2. Clean the roller slots and dirty water pipe with the maintenance brush provided.
3. Wipe the charging contacts with a dry cloth.
4. Reinstall the rollers and dirty tank in place.

D3-1—Charging Contacts

Note: Do not wash the cleaning head directly with water.

D4 Cleaning the Charging Dock Tray

D4-1—Grasp the side handles of the tray and pull upward.

D4-2—Rinse the tray with water and reinstall it in place after drying.

Note: Only remove and wash the tray. Do not wash any other parts of the charging dock.

Basic Parameters

Body

| | |
|---------------|--|
| Model | WD2H1A |
| Weight | 4.8 kg |
| Rated power | 260 W |
| Rated voltage | 21.6 V \approx |
| Charging time | < 4 hours |
| Battery | 21.6 V/4000 mAh (TYP) Lithium-ion battery |

Power Supply

| | |
|--------------|--|
| Model | YJS060P-3001900G, E060-1P300190VE or E060-1P300190VA |
| Rated input | 100–240 V ~ 50–60 Hz, 1.5 A |
| Rated output | 30 V \approx 1.9 A |
| Battery | 21.6 V/4000 mAh (TYP) Lithium-ion battery |

WiFi Specification

| | |
|-------------------|-----------------|
| Service | WiFi |
| Protocol | 802.11b/g/n |
| Frequency Range | 2400-2483.5 MHz |
| Max. Output Power | \leq 20dBm |

Common Issues

| Issue | Solution |
|---|--|
| There are large water stains on the floor, the cleaning head leaks water, or water cannot be vacuumed from the floor. | <ul style="list-style-type: none">• Remove the rollers and the dirty tank to check for a clog in the dirty water pipe or the suction outlet, and if the filter is clogged. Clear all blockages, clean the filter and make sure dirty tank and filter were properly installed before retrying. |
| The screen does not light up and the vacuum cleaner cannot start. | <ul style="list-style-type: none">• Low battery level. Charge it before use. |
| The dirty tank leaks and the filter is wet. | <ul style="list-style-type: none">• Remove and clean the two water level sensors in the dirty tank. Make sure that the body is not laid flat. |
| There is a strange smell during use. | <ul style="list-style-type: none">• Clean the rollers, dirty tank, and filter. |
| Cleaning creates a lot of bubbles. | <ul style="list-style-type: none">• Do not add detergent or disinfectants that are not recommended by Roborock to the clean tank, or spray such detergent or disinfectants on the floor. |
| The vacuum cleaner does not charge when docked. | <ul style="list-style-type: none">• Check the charging contacts on the charging dock and the corresponding part on the body. |
| The screen is on, but the buttons do not respond. | <ul style="list-style-type: none">• Press and hold the power button for 10 seconds to force restart the vacuum cleaner. |
| Unable to connect to WiFi. | <ul style="list-style-type: none">• WiFi disabled. Reset the WiFi and try again.• Poor WiFi signal. Move the vacuum cleaner to an area with good WiFi reception.• Abnormal WiFi connection. Reset the WiFi, download the latest mobile app and retry.• Unable to connect to WiFi. There may be an error with your router settings. Contact Roborock Customer Service for help with troubleshooting. |
| Is power always being drawn when the vacuum cleaner is on the dock? | <ul style="list-style-type: none">• The vacuum cleaner will draw power while it is docked to maintain battery performance, but the power consumption is extremely low. |

EU Declaration of Conformity

We Shenzhen Roborock Innovation Technology Co., Ltd. hereby declare that this equipment is in compliance with the applicable Directives and European Norms, and amendments. The full text of the EU declaration of conformity is available at the following internet address:

<https://global.roborock.com/pages/compliance>

We Shenzhen Roborock Innovation Technology Co., Ltd. hereby declare that the radio equipment type WD2H1A is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address:

<https://global.roborock.com/pages/compliance>

WEEE Information

Correct Disposal of this product. This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.



Warranty Information

The warranty period depends on the laws of the country in which the product is sold, and the warranty is the responsibility of the seller.

The warranty only covers defects in material or workmanship.

The repairs under warranty may only be carried out by an authorized service centre. When making a claim under the warranty, the original bill of purchase (with purchase date) must be submitted.

The warranty will not apply in cases of:

- Normal wear and tear.
- Incorrect use, e.g. overloading of the appliance, use of non-approved accessories, use of force.
- Damage caused by external influences.
- Damage caused by non-observance of the user manual, e.g. connection to an unsuitable mains supply or non-compliance with the installation instructions.
- Partially or completely dismantled appliances.